



Sinar FarmPro Moisture Analyser

- Easy to use
- Robust and portable
- Grinds and compresses in one action
- Clear digital readout
- Averaging facility
- Calibrated for 15 crops
- Automatic temperature compensation
- Complete with carry case and brush
- Results in seconds

Product Description

The highly portable FarmPro moisture analyser is the perfect tool for analysing the moisture content of grain, oilseeds and pulses anywhere on the farm. Its rugged construction means that it is durable enough to go anywhere you can. The FarmPro takes a very small sample, 9 or 11ml which makes it ideal for 'rubbing out' prior to harvest.

The FarmPro simultaneously cracks and crushes the sample for quick and accurate results. Simply pour the grain into the measurement cell, screw down the serrated plate and read off the moisture content. The FarmPro measures the conductance of the sample and automatically corrects for temperature. This simplicity does away with the need to mount your machine on a bench or weigh out precise quantities of samples.

With the FarmPro accurate measurements can be taken in the middle of a field with the minimum of fuss.

Product Features

Moisture range:	5% to 45% dependant on application
Operating temperature	
Range:	0 to 45°C
Readout resolution:	0.1% moisture content
Principal of operation:	Conductance
Temperature comp:	Automatic
Size:	21 x 7.5 x 7.5 cm
Weight inc. carry case:	1.5 kg
Battery:	9v Alkaline
Accuracy:	Better than $\pm 0.5\%$ mc dependant on application

000 «Диаэм»

Москва
ул. Магаданская, д. 7, к. 3 ■ тел./факс: (495) 745-0508 ■ sales@dia-m.ru

www.dia-m.ru

С.-Петербург
+7 (812) 372-6040
spb@dia-m.ru

Новосибирск
+7 (383) 328-0048
nsk@dia-m.ru

Воронеж
+7 (473) 232-4412
vrn@dia-m.ru

Йошкар-Ола
+7 (927) 880-3676
nba@dia-m.ru

Красноярск
+7 (923) 303-0152
krsk@dia-m.ru

Казань
+7 (843) 210-2080
kazan@dia-m.ru

Ростов-на-Дону
+7 (863) 303-5500
rnd@dia-m.ru

Екатеринбург
+7 (912) 658-7606
ekb@dia-m.ru

Кемерово
+7 (923) 158-6753
kemerovo@dia-m.ru

Армения
+7 (094) 01-0173
armenia@dia-m.ru

